

Corentium Home

by Airthings



DOWNLOADS



Corentium Home is a small yet powerful radon gas detector. It provides exactly what you need to stay on top of your radon levels.

FOR EVERYONE

Developed by our in-house CERN scientists, we are proud to offer a product which is accurate, simple and elegant. In short, Corentium Home is a detector for everyone.

PORTABLE

Every room in your home has different radon levels. With Corentium Home you can measure all rooms for the price of one device.

FUNCTIONS

Reset button: resets the device
Mode button: displays total days measured
Reporting: free web-based reporting
Quick: results within 24 hours

SPECIFICATIONS

Radon sampling: passive diffusion chamber
Detection method: alpha spectrometry
Measurement range: 0 – 9999 Bq/m³
Operation environment: 4°C to 40°C

LONG BATTERY LIFE

Above 2 years of continuous monitoring
Comes with replaceable AAA batteries

ACCURATE

Unaffected by other radiation
After 7 days: $\sigma < 10\%$ at 100 Bq/m³
After 2 months: $\sigma < 5\%$ at 100 Bq/m³

ADDITIONAL INFORMATION

PACKAGE CONTENTS

Radon detector
3 x alkaline batteries type AAA (LR03)
User manual

PACKAGE

Weight: 227g
Dimension: 130x77x36 mm

DETECTOR

Weight: 148g (with batteries)
Dimension: 119x69x26 mm

PRODUCT CODES

EAN: 7090031102227
SKU: 224