

EMF510 EMF/ELF Meter



The Extech EMF510 measures energy from electromagnetic fields (EMF) and electrical signals and is sensitive to extremely low frequency levels (ELF). The built-in single-axis sensor is ideal for monitoring power lines, electrical appliances, fans and blowers, and electrical circuits in two ranges with milli-Gauss and micro-Tesla units. The EMF510 features a large backlit LCD for viewing in dimly lit areas, an ergonomic compact design with wrist strap, auto power off, and Min/Max function.



Features

- Measure EMF/ELF levels in milliGauss (mG) or microTesla (μ T) up to 2000mG (200 μ T) with two ranges to choose from
- Built-in single axis sensor provides basic accuracy reading of \pm 5%
- 30 to 300Hz bandwidth
- Backlit display to view in dimly lit areas
- Data Hold and Min/Max functions
- Auto power off with disable
- Tripod mount (optional TR100 Tripod sold separately)
- Complete with wrist strap and 3 AAA batteries

Specifications	Range	Max Resolution	Basic Accuracy
Range/Resolution	200.0/2000mG 20.00/200.0 μ T	0.1/1mG 0.01/0.1 μ T	\pm (5%+3 digits) @ 50/60Hz \pm (5%+3 digits) @ 50/60Hz
Bandwidth	30 to 300Hz		
Number of Axes	Single axis		
Dimensions	4.2 x 2.3 x 1" (107 x 58 x 25mm)		
Weight	5.6oz (160g)		

Ordering

EMF510 EMF/ELF Meter



UPC Code: 793950225103

Distribuito da:
Zetalab s.r.l.

Via Umberto Giordano, 5 - 35132 Padova
Tel 049 2021144 - Fax 049 2021143
www.zetalab.it - email: info@zetalab.it

Zetalab.it