

VCDK Visual Arsenic Test Kit

The Visual Colour Detection Kit operates using the same unique 3-stage filter system as in the Palintest Digital Arsenic Test Kit, but the resulting colour change is compared and analysed against a calibrated colour chart by the user, as opposed to being measured on a colorimeter.

- Simple test protocol with packaged reagents and visual test determination.
- Employs the unique 3-stage filter system for increased sensitivity and operator safety.
- Lightweight field case containing all parts required for use.



Technical Specification

Measuring System	Colorimeter
Range	2 - 100 $\mu\text{g/L}$
Reaction time	20 minutes

Ordering Information

PT980

VCDK Visual Arsenic Test Kit

Palintest VCDK Visual Arsenic Test Kit, hard case. Includes: tri-filter arsenic trap, 100 mL reaction vessel, destruction filter (x4), detection filter holder (x4), hydrogen sulphide filter (x4), reagents for 200 tests, visual comparison chart, forceps, dilution tube, cuvette brush, and instructions.

PT983

Palintest Arsenic Refill Pack

Arsenic Refill Pack, comprising: reagents for 200 tests, arsenic detection filters (x200), arsenic destruction filters (x200), destruction filter holders (x2), detection filter holders (x2), A1 reagent sachets (x200), A2 tablet reagents (x200), hydrogen sulphide removal filters (x5).

