

HAY AND STRAW HUMIDITY MEASURING DEVICE



HIGHLIGHTS:

- o robust 60 cm V4A measuring rod
- o characteristics for hay, straw and grain

BaleCheck 100

Art. no. 600103

Hay and Straw Moisture Meter (incl. measuring rod and protective bag)

General:

The BaleCheck 100 is a professional measuring device for measuring the moisture in bales of pressed hay and straw. It allows to easily determine the suitability for storage and quality of hay and straw – important especially in agriculture, stock breeding and horse keeping. The slim but robust measuring rod should be used for measurements in different depths. If the maximal moisture is <16.0 % u, the material can be stored or spent without hesitation.

Application:

- agriculture
- processing or storing of hay or straw
- hay and straw trading
- stock breeding
- horse keeping

Specifications:

Measuring range:	0.0 ... 100 % u (material moisture) 0.0 ... 50 % w (water content)
Resolution:	0.1 % (till 19.9 %) and 1 % (from 20 %)
Characteristics:	hay, straw, grain, reference characteristics
Moisture rating:	6-step bar graph (wet ... dry)
Temperature compensation:	manual
Display:	2 displays for characteristics and measuring value
Operating conditions:	-25 ... +50 °C (device), 0 ... +100 °C (rod), 0 ... 95 % RH (non-condensing)
Measuring rod:	V4A stainless steel, 600 mm x Ø 10 mm, 1 m connection cable with BNC-plug, 260 g, design of probe handle offers comfortable operation
Power supply:	9 V battery
Battery life:	approx. 170 h
Housing:	impact-resistant ABS
Dimensions:	110 x 67 x 30 mm (H x W x D)
Weight:	155 g
Scope of supply:	Device, measuring rod GSF 40, protective bag, battery, calibration protocol, manual

HAY AND STRAW HUMIDITY MEASURING DEVICE
INCL. TEMPERATURE MEASUREMENT

HIGHLIGHTS:

- o fast temperature measurement integrated
- o robust 60 cm V4A measuring rod
- o characteristics for hay, straw and grain

BaleCheck 200

Art. no. 600354

Hay and Straw Moisture Meter incl. temperature measurement, measuring rod 620 mm

General:

The BaleCheck 200 is a professional measuring device for measuring the moisture in bales of pressed hay and straw. It allows to very precisely determine the suitability for storage and quality of hay and straw as well as grain – important especially in agriculture, stock breeding and horse keeping. The slim but robust measuring rod should be used for measurements in different depths. If the maximal moisture is <16.0 % u, the material can be stored or spent without hesitation. The additional temperature measurement makes an automatic temperature compensation possible and supports fire prevention (proof of due diligence).

Application:

- fire prevention
- agriculture
- processing / storing / trading of hay or straw
- stock breeding, horse keeping

Specifications:

Measuring range:	0.0 ... 100.0 % u (material moisture) 0.0 ... 50.0 % w (water content) -40.0 ... +200.0 °C (device)
Resolution:	0.1 %, 0.1 %
Characteristics:	hay, straw, grain, reference characteristics, approx. 480 additional material moisture characteristics
Moisture rating:	9-step bar graph (wet ... dry)
Temperature compensation:	automatic or manual
Display:	two 4-digit LCD displays (12.4 mm and 7 mm)
Operating conditions:	-25 ... +50 °C (device), 0 ... +100 °C (rod), 0 ... 95 % RH (non condensing)
Measuring rod:	V4A stainless steel, 600 mm x Ø 10 mm, 1 m connection cable with BNC-/type K- plug, temperature 0 ... 100 °C, 260 g
Features:	interface, analog output (0 ... 1 V), power supply terminal (10.5 ... 12 VDC)
Sort:	the material selection is restricted to up to 8 favorites
Power supply:	9 V battery
Battery life:	approx. 120 h
Housing:	impact-resistant ABS
Dimensions:	142 x 71 x 26 mm (H x W x D)
Weight:	155 g
Scope of supply:	Device, measuring rod GSF 40 TF with temperature sensor, protective bag, battery, calibration protocol, manual

Varianten:**BaleCheck 200 - 1000**

Art. no. 607147

Hay and Straw Moisture Meter incl. measuring rod 1000 mm

BaleCheck 200 - 1500

Art. no. 607146

Hay and Straw Moisture Meter incl. measuring rod 1500 mm

Distribuito da: **Zetalab.it**
Zetalab s.r.l.

Via Umberto Giordano, 5 - 35132 Padova
Tel 049 2021144 - Fax 049 2021143
www.zetalab.it - email: info@zetalab.it